

200ATS零件目录图册

200ATS PARTS LIST




FOREWORD

When you are going to order parts you may take this booklet as reference but any differences please take the reality on vehicle as standard.


To find out the name, Item code or fitment you may check in the illustration with the size and appearance .Then with the no. in the illustration you will find out the name, item code and quantity.

There will no notice to you ahead of any change of the information in this booklet.


发动机 (ENGINE)

[illegible]


E-1 曲轴箱组合 CRANKCASE ASSY

[illegible]


E-2 曲轴箱盖组件 CRANKCASE COVER ASSY

[illegible]

E-3 气缸头 气缸头盖总成 CYLINDER HEAD & CYLINDER HEAD COVER ASSY

[illegible]


E-4 曲轴 活塞连杆总成 CRANKSHAFT, PISTON & CONNECTING

[illegible]


E-5 凸轮轴组合 气门摇臂组合 COMBINATION OF CAMSHAFT & VALVE ROCKER



E-12 飞轮部件 FLYWHEEL

[illegible]

E-13 点火线圈组件 IGNITION COIL

[illegible]


传动部件 Transmission

[illegible]

车架附件1 Frame & Accessories 1

[illegible]

护杠&附件 Frame & Accessories 2


[illegible]

This diagram illustrates the exploded view of a bicycle front fork assembly. The components are numbered as follows:


- 1**: Fork crown (the main frame connecting the handlebars to the stem).
- 2**: Top cap (the cap that fits over the top of the fork crown).
- 3**: Handlebars (the bars used to steer the bicycle).
- 4**: Stem cap (the cap that fits over the top of the stem).
- 5**: Stem (the vertical tube that connects the fork crown to the handlebars).
- 6**: Fork blades (the two main tubes that support the front wheel).
- 7**: Fork end cap (the cap that fits over the end of the fork blades).
- 8**: Fork end cap (the cap that fits over the end of the fork blades).
- 9**: Fork end cap (the cap that fits over the end of the fork blades).
- 10**: Fork end cap (the cap that fits over the end of the fork blades).
- 11**: Fork end cap (the cap that fits over the end of the fork blades).
- 12**: Fork end cap (the cap that fits over the end of the fork blades).

第 16 页

前後碟刹 Brake system

[illegible]

后轴总成 Rear Axle ASSY



序	件 号	中 文 名 称	英 文 名 称	数量	单价 (Unit Price)	
NO.	Code name	Chinese	Description	Q'ty	¥	\$
1	02040438	后桥轴	Rear Axle	1		
2	02040159	链条 (530-126节)	Chain (530-126Links)	1		
3	02040160	链条接头 (530)	Chain Lock Link (530)	1		
4	07020136	张紧器扭簧	spring; chain tensioner	1		
5	02012180	张紧器摇臂组件	Tensioner rocker assembly	1		
6	06990100-1	拖轮组件	Tugboats ASSY	1		
7	14020773	张紧器摇臂/内衬套	Bush,Tensioner rocker	1		
8	02040375	牙盘	Sprocket	1		
9	02012167	调链器	Chain adjuster	1		
10	02040426	轴承座 (左)	Bearing seater(left)	1		
11	02040427	轴承座 (右)	Bearing seater(right)	1		
12	14020772	后轴衬套	Bush ,rear axle	2		
13	02040105	后轮毂座	Rear wheel hub seat	2		
14	02011053	碗型垫片	Bowl washer	2		
15		弹垫M16	Spring Washer M16	2		
16		开槽螺母M16	Slotted Nut M16	2		
17		开口销3. 0*40	Pin 3.0-40	2		
18						
19						
20						

操纵系统 Control Assy


[illegible]

供给系统 OIL SUPPLY SYSTEM




序	件 号	中 文 名 称	英 文 名 称	数量	单价 (Unit Price)	
NO.	Code name	Chinese	Description	Q'ty	¥	\$
1	05030069	铁油箱	Fuel tank	1		
2	05050015	油箱盖	Cap,fuel tank	1		
3	01040051	空滤器连接管	Connection rod ,air filter	1		
4	01040040	空滤器	Air Filter	1		
5	06030002	汽油管4.5*8.5(38CM)	Gasoline pipe(4.5*8.5)38CM	1		
6	12010007	油管夹8.5	Tubing clamp 8.5	3		
7	06990001	二级过滤器	Secondary Filter	1		
8	01050100	消声器前管	Exhaust Pipe	1		
9	1990062	DPE补气阀	DPE air make-up valve	1		
10	07020102	消声器拉簧(L:60, φ2)	Tension spring (L:60, φ2)	2		
11	01050015-2	消声器	Muffler Cylinder	1		
12						
13						
14						
15						
16						
17						
18						
19						
20						

前后轮总成 Front&Rear Wheel ASSY

[illegible]

电器/开关 Electrical Components, Switches

[illegible]

覆盖件 Body Covering

[illegible]

随车工具 Tool Kit

[illegible]