

DF200SST零件目录图册




FOREWORD

When you are going to order parts you may take this booklet as reference but any differences please take the reality on vehicle as standard.

To find out the name, Item code or fitment you may check in the illustration with the size and appearance .Then with the no. in the illustration you will find out the name, item code and quantity.


There will no notice to you ahead of any change of the information in this booklet.

曲轴箱总成 (1) Crankcase 1




序	件号	中文名称	英文名称	数量		
NO	Code name	Chinese	Description	Q'ty		
1	2.20.05.67.02000	右箱体	R.Crankcase Assembly	1		
2	1.20.04.01.12000	通气管组合	Breather Pipe Assembly	1		
3	2.20.04.67.07000	左箱体本体总成	L.Crankcase Assembly	1		
4	1.20.04.01.08000	后减震套	Rear Shock Absorber Sheath	1		
5	1.00.01.6004-2RS	轴承6004-2RS	Bearing 6004-2RS	1		
6	1.20.04.01.10000	输出轴油封27×42×7	Oil Seal of Output Shaft	1		
7	1.00.01.6301	轴承6301	Bearing 6301	1		
8	1.00.01.6002	轴承6002	Bearing 6002	1		
9	1.20.04.01.13000	曲轴油封19.8×30×5	Oil Seal 19.8×30×5	1		
10	1.20.04.01.14000	放油螺栓M12×1.5×14	Bolt M12×1.5×14	1		
11	1.20.04.01.03000	平垫 12×18×1	Rear Gasket 12×18×1	1		
12	1.20.04.01.09000	前减震套	Front Shock Absorber Sheath	2		
13	1.20.13.01.01000	固定拉力杆螺钉	Screw	1		
14	1.20.13.01.02000	O形圈16×1.5	O-Ring 16×1.5	1		
15	1.20.13.01.05000	拉力杆	Tension Rod	1		
16	1.20.13.32.04000	正时链条	Timing Chain	1		
17	1.20.13.01.06000	分气链条导件	Chain Guide	1		
18	1.20.04.06.04000	双头螺柱M8×209	Stud Bolt M8×209	2		
19	1.20.05.06.01000	双头螺柱M8×201	Stud Bolt M8×201	2		
20	1.20.04.01.05000	右箱体垫	Gasket	1		
21	1.20.04.01.01000	定位套 ø8×14	Locating Bush ø8×14	2		
22	1.05.01.09.0650	螺栓M6×50	Bolt M6×50	2		
23	1.05.04.01.0800	螺母SM8	Nut M8	1		
24	1.20.04.01.11000	O形圈7.5×1.5	O-Ring 7.5×1.5	1		
25	1.20.04.03.02000	刹车销	Brake Pin	1		

右箱体端盖总成 (5) Right Crankcase Cover Assy




序	件号	中文名称	英文名称	数量		
NO	Code name	Chinese	Description	Q'ty		
1	2.20.07.01.01000	右盖	Right Cover	1		
2	1.20.07.01.06000	右盖垫	Gasket,Right Cover	1		
3	1.20.04.01.13000	曲轴油封19.8×30×5	Oil Seal 19.8×30×5	1		
4	1.20.04.01.01000	定位套φ8×14	Locating Bush φ8×14	2		
5	1.20.07.01.09000	滤油网	Oil-Filter Screen	1		
6	1.20.07.01.03000	滤油网弹簧	Spring,Oil-Filter Screen	1		
7	1.20.07.01.04000	O形圈30.5×3	O-Ring 30.5×3	1		
8	1.20.07.01.02000	滤油网螺帽	Oil-Filter Screen Nut	1		
9	1.05.01.09.0632	螺栓M6×32	Bolt M6×32	1		
10	1.05.01.09.0695	螺栓M6×95	Bolt M6×95	4		
11	1.05.01.09.06100	螺栓M6×100	Bolt M6×100	1		
12	1.05.01.09.06110	螺栓M6×110	Bolt M6×110	2		
13	1.20.07.01.08000	触发线卡	Trigger Line Card	1		
14	1.20.07.01.05000	机油尺	Oil Level Gauger	1		
15	1.20.07.01.07000	O形圈18×3	O-Ring 18×3	1		
16	1.05.01.09.0635	螺栓M6×35	Bolt M6×35	1		
17	2.20.07.01.99000	右盖总成	Right Cover Assy	1		

气缸头总成 (7) Cylinder Head ASSY



序	件号	中文名称	英文名称	数量		
NO	Code name	Chinese	Description	Q'ty		
1	2.20.01.67.13001	气缸头组 (补气状态)	Cylinder Head ASSY	1		
2	1.05.01.09.06100	螺栓M6×100	Bolt M6×100	2		
3	1.20.01.01.01000	定位套φ10×16	Locating Bush φ10×16	4		
4	1.20.01.09.15000	气缸头垫片	Cylinder Head Gasket	1		
5	1.20.01.01.16010	进气管夹	Pipe Clamp	1		
6	1.05.02.01.0425	螺钉M4×25	Screw M4×25	1		
7	1.05.04.02.0600	螺母M6	Nut M6	2		
8	1.20.01.01.16000	进气管总成	Intake-Tube Assy	1		
9	1.00.14.265180	O形圈26.5×1.8	O-Ring 26.5×1.8	1		
10	1.20.01.01.12000	隔热板	Thermal Baffle	1		
11	1.20.01.01.11000	垫板	Base Plate	1		
12	1.20.01.06.06000	进气门	Inlet Valve	1		
13	1.20.01.01.14000	气门油封	Oil Seal,Valve	2		
14	1.20.01.01.10000	垫片	Gasket	2		
15	1.20.01.06.09000	气门外弹簧	Outer Valve Spring	2		
16	1.20.01.06.08000	气门内弹簧	Inner Valve Spring	2		
17	1.20.01.01.05000	气门弹簧座	Valve Spring Retainer	2		
18	1.20.01.01.07000	气门锁块	Valve Cotter	4		
19	1.20.01.01.17000	火花塞	Spark Plug	1		
20	1.20.12.01.05000	止动板组	Stop Plate	1		
21	1.20.12.01.04020	调整螺母	Adjusting Nut	2		
22	1.20.12.01.04030	调整螺丝	Adjusting Screw	2		
23	1.20.12.06.04010	摇臂	Rocker Arm	2		
24	1.20.12.06.03000	进气摇臂轴组	Inlet Rocker Arm Shaft Assy	1		

磁电机部件、机油泵部件




序	件号	中文名称	英文名称	数量		
NO	Code name	Chinese	Description	Q'ty		
1	1.05.01.09.0618	螺栓M6×18	Bolt M6X18	4		
2	1.20.24.01.06000	风扇组合	Fan Assy	1		
3	1.05.04.10.1213	螺母M12×1.25 H=10	Nut M12X1.25 H=10	1		
4	1.05.05.04.1201	平垫12-14HV	Washer 12-14 HV	1		
5	1.20.16.01.01020	飞轮	Flywheel(Rotor)	1		
6	1.05.01.09.0620	螺栓M6×20	Bolt M6X20	2		
7	1.05.01.08.0512	六角螺栓M5×12	Hex Bolt M5X12	2		
8	1.20.14.01.03000	机油泵组合	Oil Pump Assy	1		
9	1.05.01.09.0625	螺栓M6×25	Bolt M6X25	2		
10	1.20.14.01.01000	油泵链轮	Oil pump sprocket	1		
11	1.05.04.02.0600	螺母M6	Nut M6	1		
12	1.20.14.01.04000	油泵链条	Oil pump Chain	1		
13	1.20.14.01.02000	链轮端盖	Sprocket side Cover	1		
14	1.05.01.09.0612	螺栓M6×12	Bolt M6X12	2		
15	1.20.16.01.01011	定子组件(直流8级)	Stator (DC 8 pole)	1		
15	1.20.16.01.01012	定子组件(直流11级)	Stator (DC 11 pole)	1		
16	1.20.16.01.01001	磁电机总成(直流8级)	Magneto (DC 8 pole)	1		
16	1.20.16.01.01002	磁电机总成(直流11级)	Magneto (DC 11 pole)	1		

车架、搁脚组合 Frame and Foot Pedal




序	件号	中文名称	英文名称	数量		
NO	Code name	Chinese	Description	Q'ty		
1	02011021	头罩前支架	Head cover front bracket	1		
2	12030046	320-22圆锥滚子轴承	320-22 tapered roller bearing	1		
3	0201-200SST	车架	Frame	1		
A	02050039	搁脚组合前右	Front right footrest assembly	1		
4	/	刹车踏板	Brake pedal	1		
5	/	前右脚蹬	Front right foot peg	1		
6	02011143	坐垫支架	Seat bracket	1		
7	07020061	单撑弹簧 $\phi 2.5 \times 100\text{mm}$	Side stand spring $\phi 2.5 \times 100\text{mm}$	1		
8	02010424	单撑 CA250	Side stand CA250	1		
9	/	前搁脚支架右	Front right footrest bracket	1		
B	02050038	搁脚组合前左	Front left footrest assembly	1		
10	/	前搁脚支架左	Front left footrest bracket	1		
11	/	刹车踏板弹簧	Brake pedal spring	1		
12	/	前左脚蹬	Front left foot peg	1		
13	03030801	后扶手左	Left rear grab handle	1		
14	03030802	后扶手右	Right rear grab handle	1		
15	12030047	320-23圆锥滚子轴承	320-23 tapered roller bearing	1		
16	/	单撑螺丝 $M10 \times 1.25 \times \phi 12 \times 15 \times 25$	Side stand screw $M10 \times 1.25 \times \phi 12 \times 15 \times 25$	1		

转向系统、减震系统 SUSPENSION



序 NO	件 号 Code name	中文名称 Chinese	英文名称 Description	数量 Q'ty		
1	02030203	上联板	Upper triple clamp	1		
2	02030204	下联板	Lower triple clamp	1		
3	02030202	手把管固定座右	Right handlebar fixing base	1		
4	02030200	手把管	Handlebar tube	2		
5	10010077	右组合开关	Right combination switch	1		
6	10020056	油门把套	Throttle grip	1		
7	02030201	手把管固定座左	Left handlebar fixing base	1		
8	10010076	左组合开关	Left combination switch	1		
9	10020055	左把套	Left grip	1		
10	07010100	前减震器	Front shock absorber	1		
11			Reflector (round, orange)	1		
12	09050002	(圆、橙色) 反光片	Right front fender bracket	2		
13	02011025	前泥板支架右	Left front fender bracket	1		
14	02011024	前泥板支架左	Steering column	1		
15	02030205	方向柱	Rear shock absorber	1		
16	07010112	后减震	Front wheel bushing	1		
17	02011015	前轮衬套	Bush,Front Fender	2		

覆盖件1 Body Covering 1



序	件号	中文名称	英文名称	数量		
NO	Code name	Chinese	Description	Q'ty		
1	03030592	油箱边侧板左	Left side panel of fuel tank edge	1		
2	03030593	油箱边侧板右	Right side panel of fuel tank edge	1		
3	03030590	侧板左	Left side panel	1		
4	03030591	侧板右	Right side panel	1		
5	03030594	后泥板	Rear fender	1		
6	03030600	鹰嘴	Eagle beak	1		
7	03030597	下网罩左	Left lower mesh cover	1		
8	03030598	下网罩右	Right lower mesh cover	1		
9	03030595	上网罩左	Left upper mesh cover	1		
10	03030596	上网罩右	Right upper mesh cover	1		
11	03010389	尾灯壳	Tail light shell	1		
12	03030599	挡风玻璃	Windshield	1		
13	03030589	电池盒	Battery box	1		
14	03030493	电池盒盖	Battery box cover	1		
15	02011014	后泥板固定板	Rear fender fixing plate	1		
16	09050001	反光片(方-红)	Reflector (square - red)	1		
17	03030422	G300网罩	G300 mesh cover	1		
18	03030311	工具箱	Tool box	1		
19	02011029	电瓶盖扣板	Battery cover buckle plate	2		

