

# DF200SVT零件目录图册



## FOREWORD


When you are going to order parts you may take this booklet as reference but any differences please take the reality on vehicle as standard.

To find out the name, Item code or fitment you may check in the illustration with the size and appearance .Then with the no. in the illustration you will find out the name, item code and quantity.

There will no notice to you ahead of any change of the information in this booklet.



## 曲轴箱总成 (1) Crankcase 1




序	件号	中文名称	英文名称	数量		
NO	Code name	Chinese	Description	Q'ty		
1	2.20.05.67.02000	右箱体	R.Crankcase Assembly	1		
2	1.20.04.01.12000	通气管组合	Breather Pipe Assembly	1		
3	2.20.04.67.07000	左箱体本体总成	L.Crankcase Assembly	1		
4	1.20.04.01.08000	后减震套	Rear Shock Absorber Sheath	1		
5	1.00.01.6004-2RS	轴承6004-2RS	Bearing 6004-2RS	1		
6	1.20.04.01.10000	输出轴油封27×42×7	Oil Seal of Output Shaft	1		
7	1.00.01.6301	轴承6301	Bearing 6301	1		
8	1.00.01.6002	轴承6002	Bearing 6002	1		
9	1.20.04.01.13000	曲轴油封19.8×30×5	Oil Seal 19.8×30×5	1		
10	1.20.04.01.14000	放油螺栓M12×1.5×14	Bolt M12×1.5×14	1		
11	1.20.04.01.03000	平垫 12×18×1	Rear Gasket 12×18×1	1		
12	1.20.04.01.09000	前减震套	Front Shock Absorber Sheath	2		
13	1.20.13.01.01000	固定拉力杆螺钉	Screw	1		
14	1.20.13.01.02000	O形圈16×1.5	O-Ring 16×1.5	1		
15	1.20.13.01.05000	拉力杆	Tension Rod	1		
16	1.20.13.32.04000	正时链条	Timing Chain	1		
17	1.20.13.01.06000	分气链条导件	Chain Guide	1		
18	1.20.04.06.04000	双头螺柱M8×209	Stud Bolt M8×209	2		
19	1.20.05.06.01000	双头螺柱M8×201	Stud Bolt M8×201	2		
20	1.20.04.01.05000	右箱体垫	Gasket	1		
21	1.20.04.01.01000	定位套 ø8×14	Locating Bush ø8×14	2		
22	1.05.01.09.0650	螺栓M6×50	Bolt M6×50	2		
23	1.05.04.01.0800	螺母SM8	Nut M8	1		
24	1.20.04.01.11000	O形圈7.5×1.5	O-Ring 7.5×1.5	1		
25	1.20.04.03.02000	刹车销	Brake Pin	1		








右箱体端盖总成 (5) Right Crankcase Cover Assy



序	件号	中文名称	英文名称	数量		
NO	Code name	Chinese	Description	Q'ty		
1	2.20.07.01.01000	右盖	Right Cover	1		
2	1.20.07.01.06000	右盖垫	Gasket,Right Cover	1		
3	1.20.04.01.13000	曲轴油封19.8×30×5	Oil Seal 19.8×30×5	1		
4	1.20.04.01.01000	定位套φ8×14	Locating Bush φ8×14	2		
5	1.20.07.01.09000	滤油网	Oil-Filter Screen	1		
6	1.20.07.01.03000	滤油网弹簧	Spring,Oil-Filter Screen	1		
7	1.20.07.01.04000	O形圈30.5×3	O-Ring 30.5×3	1		
8	1.20.07.01.02000	滤油网螺帽	Oil-Filter Screen Nut	1		
9	1.05.01.09.0632	螺栓M6×32	Bolt M6×32	1		
10	1.05.01.09.0695	螺栓M6×95	Bolt M6×95	4		
11	1.05.01.09.06100	螺栓M6×100	Bolt M6×100	1		
12	1.05.01.09.06110	螺栓M6×110	Bolt M6×110	2		
13	1.20.07.01.08000	触发线卡	Trigger Line Card	1		
14	1.20.07.01.05000	机油尺	Oil Level Gauger	1		
15	1.20.07.01.07000	O形圈18×3	O-Ring 18×3	1		
16	1.05.01.09.0635	螺栓M6×35	Bolt M6×35	1		
17	2.20.07.01.99000	右盖总成	Right Cover Assy	1		



## 气缸头总成 (7) Cylinder Head ASSY



序	件号	中文名称	英文名称	数量		
NO	Code name	Chinese	Description	Q'ty		
1	2.20.01.67.13001	气缸头组 (补气状态)	Cylinder Head ASSY	1		
2	1.05.01.09.06100	螺栓M6×100	Bolt M6×100	2		
3	1.20.01.01.01000	定位套φ10×16	Locating Bush φ10×16	4		
4	1.20.01.09.15000	气缸头垫片	Cylinder Head Gasket	1		
5	1.20.01.01.16010	进气管夹	Pipe Clamp	1		
6	1.05.02.01.0425	螺钉M4×25	Screw M4×25	1		
7	1.05.04.02.0600	螺母M6	Nut M6	2		
8	1.20.01.01.16000	进气管总成	Intake-Tube Assy	1		
9	1.00.14.265180	O形圈26.5×1.8	O-Ring 26.5×1.8	1		
10	1.20.01.01.12000	隔热板	Thermal Baffle	1		
11	1.20.01.01.11000	垫板	Base Plate	1		
12	1.20.01.06.06000	进气门	Inlet Valve	1		
13	1.20.01.01.14000	气门油封	Oil Seal,Valve	2		
14	1.20.01.01.10000	垫片	Gasket	2		
15	1.20.01.06.09000	气门外弹簧	Outer Valve Spring	2		
16	1.20.01.06.08000	气门内弹簧	Inner Valve Spring	2		
17	1.20.01.01.05000	气门弹簧座	Valve Spring Retainer	2		
18	1.20.01.01.07000	气门锁块	Valve Cotter	4		
19	1.20.01.01.17000	火花塞	Spark Plug	1		
20	1.20.12.01.05000	止动板组	Stop Plate	1		
21	1.20.12.01.04020	调整螺母	Adjusting Nut	2		
22	1.20.12.01.04030	调整螺丝	Adjusting Screw	2		
23	1.20.12.06.04010	摇臂	Rocker Arm	2		
24	1.20.12.06.03000	进气摇臂轴组	Inlet Rocker Arm Shaft Assy	1		












磁电机部件、机油泵部件




序	件号	中文名称	英文名称	数量
NO	Code name	Chinese	Description	Q'ty
1	1.05.01.09.0618	螺栓M6×18	Bolt M6X18	4
2	1.20.24.01.06000	风扇组合	Fan Assy	1
3	1.05.04.10.1213	螺母M12×1.25 H=10	Nut M12X1.25 H=10	1
4	1.05.05.04.1201	平垫12-14HV	Washer 12-14 HV	1
5	1.20.16.01.01020	飞轮	Flywheel(Rotor)	1
6	1.05.01.09.0620	螺栓M6×20	Bolt M6X20	2
7	1.05.01.08.0512	六角螺栓M5×12	Hex Bolt M5X12	2
8	1.20.14.01.03000	机油泵组合	Oil Pump Assy	1
9	1.05.01.09.0625	螺栓M6×25	Bolt M6X25	2
10	1.20.14.01.01000	油泵链轮	Oil pump sprocket	1
11	1.05.04.02.0600	螺母M6	Nut M6	1
12	1.20.14.01.04000	油泵链条	Oil pump Chain	1
13	1.20.14.01.02000	链轮端盖	Sprocket side Cover	1
14	1.05.01.09.0612	螺栓M6×12	Bolt M6X12	2
15	1.20.16.01.01012	定子组件(直流11级)	Stator (DC 11 pole)	1
16	1.20.16.01.01002	磁电机总成(直流11级)	Magneto (DC 11 pole)	1






## 车架和附件 Frame and Accessory



序	件号	中文名称	英文名称	数量		
NO	Code name	Chinese	Description	Q'ty		
1	0201-200SVT	车架	Frame ASSY	1		
2	02011651	大灯支架	Headlight bracket	1		
3	02011364	电门锁支架	Bracket, main switch	1		
4	02012263	吊架	Hanger	1		
5	02012286	后扶手	Rear carrier	1		
6	02012151	牌照支架	Licence bracket	1		
7	02011655	后泥板支架	Bracket, rear fender	1		
8	02012261	单撑 (长240mm)	Side stand	1		
9		单撑螺丝 $\Phi 16 \times 18 \times M12 \times 1.25$	Bolt, side stand $\Phi 16 \times 18 \times M12 \times 1.25$	1		
10	07020138	单撑弹簧	Spring, side stand	1		
11	02050062	搁脚左	Left footrest	1		
12	02050063	搁脚右	Right footrest	1		
13	02012262	后减震安装座	Rear shock absorber mounting base	1		
14	02011652	电瓶压板	Battery pressure plate	1		
15	12990030	碟刹管线夹	Clamp, brake hose	1		
16	02012150-1	动力连接板 (轴套 $\Phi 17.5 \times \Phi 25 \times 32$ , $\Phi 17.5 \times \Phi 25 \times 6$ )	Power connection plate (BUSH $\Phi 17.5 \times \Phi 25 \times 32$ , $\Phi 17.5 \times \Phi$	1		
17	02011657	转向灯支架压块左	Turn signal pressure bracket left	1		
18	02011658	转向灯支架压块右	Turn signal pressure bracket right	1		



## 供给系统 Supply System



序	件号	中文名称	英文名称	数量		
NO	Code name	Chinese	Description	Q'ty		
1	05030062	油箱	Fuel tank	1		
2	10040072	油位传感器	Fuel sensor	1		
3	10060001	油箱开关	Fuel switch	1		
4	01040012-1	空滤器	Air clearer	1		
5	190098	空滤器滤芯	Air filter	1		
6	06030006-1	汽油管Φ4.5*Φ8.5	Fuel pipe	1		
7	12010007	油管夹8.5	Oil pipe clamp 8.5	2		
8	06990001	二级过滤器	Secondary filter	1		
9	01030013-2	化油器	Carburetor	1		
10	01990041	二次补气装置	Secondary air supply device	1		
11	02010351	二次补气阀固定片	Bracket,air feed device	1		
12	06030001-2	真空管Φ4X7	Vacuum tube Φ 4X7	1		
13	12010010	钢丝卡子Φ6	Steel wire clip Φ6	2		
14	01050123	消声器前管	Muffler front pipe	1		
15	01990024	排气管垫	Gasket,muffler	1		
16	01050124	弹簧	Spring	2		
17		消声器筒体/小黄蜂款	Muffle pipe	1		





电气系统 ELECTRICAL SYSTEM



序 NO	件号 Code name	中文名称 Chinese	英文名称 Description	数量 Q'ty		
1	10080046	套锁	Lock Sets	1		
2	01020011	闪光器	Flasher	1		
3	01020022	高压包	Ignition Coil	1		
4	01020021	继电器	Relay	1		
5	10070001	喇叭	Horn	1		
6	08010163	电缆线	Harness	1		
7	01020017-2	整流器	Rectifier	1		
8	01020016	点火器	CDI	1		
9	09010080	大灯	Headlight	1		
10	10050097	仪表	Speedometer	1		
11	10010095	左组合开关	Switch ASSY,Left	1		
12	10010096	右组合开关	Switch ASSY,Right	1		
13	09020131	前左转向灯	Front Turnlight,Left	1		
14	09020132	前右转向灯	Front Turnlight,Right	1		
15	09020133	后左转向灯	Rear Turnlight,Left	1		
16	09020134	后右转向灯	Rear Turnlight,Right	1		
17	09030065	尾灯	Taillight	1		
18	09030066	牌照灯	Licence light	1		
19	10990001	电瓶 (12V7AH, MG7A-BS-C)	Battery ( 151*87*97)	1		
				1		

喷漆件 Painting Covering



序	件号	中文名称	英文名称	数量		
NO	Code name	Chinese	Description	Q'ty		
1	03010629	前挡泥板	Front fender	1		
2	03010634	大灯外罩	Outer cover ;headlight	1		
3	03010625	前转向灯支架左(YM826-2L)	Front turn signal bracket left	1		
4	03010626	前转向灯支架右(YM826-2R)	Front turn signal bracket right	1		
5	03010630	侧盖上段左(YM826-3L)	Left side cover upper section	1		
6	03010631	侧盖上段右(YM826-3R)	Right side cover upper section	1		
7	03010632	侧盖前段左(YM826-4L)	Left side cover front section	1		
8	03010633	侧盖前段右(YM826-4R)	Right side cover front section	1		
9	03010623	侧盖装饰盖左(YM826-44L)	Side cover decorative cover left	1		
10	03010624	侧盖装饰盖右(YM826-44R)	Side cover decorative cover right	1		
11	03010621	侧盖后段左(YM826-5L)	Left side cover rear section	1		
12	03010622-1	侧盖后段右(YM826-5R)	Right side cover rear section	1		
13	03010635	电池盒护罩上装饰盖左(YM826-45L)	Left decorative cover on battery box	1		
14	03010636	电池盒护罩下装饰盖右(YM826-45R)	Right decorative cover on battery box	1		
15	03010637	电池盒护罩小装饰盖左(YM826-46L)	Battery box small decorative cover left	1		
16	03010638	电池盒护罩小装饰盖右(YM826-46R)	Battery box small decorative cover right	1		
17	03010627	尾罩左(YM826-7L)	Tail cover left	1		
18	03010628	尾罩右(YM826-7R)	Tail cover right	1		

## 覆盖件2 Body Covering 2



序	件号	中文名称	英文名称	数量		
NO	Code name	Chinese	Description	Q'ty		
1	03030885	侧盖前连接条 (YM826-10)	Side cover front connection strip	1		
2	03030892	电池盒前罩 (YM826-42)	Battery box front cover	1		
3	03030893	电池盒护罩左 (YM826-43L)	Battery box cover left	1		
4	03030894	电池盒护罩右 (YM826-43R)	Battery box cover right	1		
5	03030889	油箱外罩 (YM826-12)	Fuel tank cover	1		
6	03030890	油箱内罩 (YM826-13)	Fuel tank inner cover	1		
7	03030886	侧盖装饰件左 (YM826-41)	Side cover trim left	1		
8	03030887	侧盖装饰件右 (YM826-41)	Side cover trim right	1		
9	03030880	电池盒	Battery box	1		
10	03030891	坐垫锁盒 (YM826-14)	Seater lock box	1		
11	03030882	尾盖 (YM826-18)	Tail cap	1		
12	03030884	后挡泥板下罩 (YM826-15)	Rear fender lower cover	1		
13	03030883	后挡泥板	Rear fender	1		
14	09050002	圆橙色反光片M5	Round orange reflector M5	2		
15	09050001	方反光片M5	Square reflector	1		
16	09050003	圆红色反光片M5	Round red reflector M5	2		
17	09060027	后视镜	Rear mirrow	1set		
18	05010071	座垫	Seater	1		
19						
20						
21						



