

DF50STT零件目录图册

DF50STT PARTSLIST




FOREWORD

When you are going to order parts you may take this booklet as reference but any differences please take the reality on vehicle as standard.

To find out the name, Item code or fitment you may check in the illustration with the size and appearance .Then with the no. in the illustration you will find out the name, item code and quantity.


There will no notice to you ahead of any change of the information in this booklet.

气缸头总成— Cylinder head assembly 1



序 NO.	件号 Code name	中文名称 Chinese	英文名称 Description	数量 Q'ty	¥	单价 \$
1	139220001	六角法兰面螺母M7	Hexagon nut M7	4		
2	139220002	平垫片Φ7×14	Washer Φ7×14	4		
3	139220003	气门摇臂座	Retainer, valve rocker	1		
4	139220004	气门摇臂	Arm, Valve rocker	2		
5	139220005	气门调整螺钉	Screw, lappet adjusting	2		
6	139220006	锁紧螺母M5	Lock nut	2		
7	139220007	进气门摇臂轴	In valve rocker axis	1		
8	139220008	排气门摇臂轴	Out valve rocker axis	1		
9	139220009	凸轮轴	Camshaft	1		
10	139220010	定位销Φ8×14	pinΦ8×14	2		
11	139220011	六角法兰面螺柱M6×85	Hexagon screw M6×85	2		
12	139220012	隔热板	Heat insulation plate	1		
13	139220013	隔热板垫	Mat of heat insulation	1		
14	2.20.01.12.13001	气缸头	Cylinder head	1		
15	139220015	排气门	Exit valve	1		
16	139220016	气门大弹簧	Valve spring big	2		
17	139220017	气门小弹簧	Valve spring small	2		
18	139220018	气门锁夹	Cotter, valve	4		
19	139220019	排气门弹簧保持器	Spring holding	1		
20	139220020	进气门	In valve	1		
21	139220021	进气门导管	In valve leader	1		
22	139220022	排气门导管	Out valve leader	1		
A	2.20.01.11.99001	气缸头总成(二次补气)	Cylinder head assembly	1		
B	139000001	凸轮轴座总成	Camshaft seat assembly	1		

曲轴、气缸总成 Crankshaft, Cylinder assembly




序 NO.	件号 Code name	中文名称 Chinese	英文名称 Description	数量		单价
				Q'ty	¥	
1	1.20.02.12.03000	气缸体	Cylinder	1		
2	139230002	气缸(纸)垫片	Gasket, cylinder	1		
3	139230003	链条调整器	Chain adjuster	1		
4	139230004	链条调整器垫片	Chain adjuster washer	1		
5	139220010	定位销Φ8×14	Pin Φ8×14	2		
6	139230005	调整器弹簧	Adjuster spring	1		
7	139230006	调整器弹簧固定螺母	Nut of adjuster spring	1		
8	139230007	固定螺母垫圈	Washer of nut	1		
9	139230008	六角法兰面螺栓M6×18	Hexagon M6×18	2		
10	139230009	导件	Guider	1		
11	1.20.10.12.03000	活塞销	Stopcock pin	1		
12	1.20.10.12.01000	活塞	Stopcock	1		
13	139230012	卡簧	Clip	2		
14						
15						
16						
17	139230016	曲轴连杆组合	Crankshaft comp.	1		
18	139230017	正时链条	Cam chain	1		
19	139230018	张紧杆	Cam chain tensioner	1		
20	139230019	张紧杆固定螺栓	Cam chain tensioner bolt	1		
21	139230020	O形环Φ15.2×1.5	O-ringΦ15.2×1.5	1		
A	1.20.10.12.02000	活塞环组合	Piston ring combination	1		
B	147000007	80CC活塞总成(带销、挡圈)	80CC Piston assembly	1		

左边盖总成 Left cover assembly




序 NO.	件号 Code name	中文名称 Chinese	英文名称 Description	数量 Q'ty	¥	单价 \$
1	139240001-1	左边盖 (加长)	Left cover	1		
2	139240002	脚起动踏杆组	Kick start lever assy	1		
3	139010004	六角法兰面螺栓M6×20	Hexagon bolt M6×20	1		
4	139240003	六角法兰面螺栓M6×35	Hexagon bolt M6×35	8		
5	139240004	线扣	Clip	1		
6	139240005	起动轴垫圈	Starting axis washer	1		
7	139240006	外卡簧	Clip	1		
8	139240007-1	左边盖垫片 (加长)	Washer of left cover	1		
8	139240007	左边盖垫片	Washer of left cover	1		
9	139220010	定位销Φ8×14	Pin, dowelΦ8×14	2		
10	139240008	起动扭簧	Starter spring	1		
11	139240009	起动惰轮组	Ldle gear	1		
12	139240010	起动齿轮	Starting gear	1		
13	139240011	磨擦弹簧	Attrition spring	1		
14	139240012	扇形齿轮衬套	Sector gear bushing	1		
15	139240013	通风管	Vent pipe	1		
16	139240014	自攻螺钉ST3.8×16	Self-tapping screw ST3.8×16	1		
17	139240015	塑料垫圈Φ35	Plastic washerΦ35	1		

驱动轮 Driving Wheel




序 NO.	件号 Code name	中文名称 Chinese	英文名称 Description	数量 Q'ty	¥	单价 \$
1	1. 20. 22. 10. 02002	皮带 729 17.7 30	Strap 729 17.7 30	1		
2	139250002	六角头螺母M12	Hexagon nut M12	1		
3	139250003	平垫片Φ12×20	WasherΦ12×20	1		
A	1. 20. 21. 12. 01000	主动轮总成	Driving wheel assembly	1		
4	139250004	主动轮压块	Driver shoe	1		
5	139250005	主动皮带扇叶盘	Initiative strap fan plate	1		
6	139250006	主动齿轮盘	Initiative gear plate	1		
7	139250007	主动轮衬套Φ20×38	Driver bushingΦ20×38	1		
8	139250008	滑动式驱动盘	Glide drive plate	1		
9	139250009	滑动滚子	roller	6		
10	139250010	斜坡板	Brae board	1		
11	139250011	斜坡板边件	Side parts of brae board	3		

机油泵 Oil Pump




序 NO.	件号 Code name	中文名称 Chinese	英文名称 Description	数量 Q'ty	¥	单价 \$
1	139300001	机油泵驱动轮	Pump drive wheel	1		
2	139160004	六角法兰面螺母M6	Hexagon nut M6	1		
3	139010004	六角法兰面螺栓M6×20	Hexagon bolt M6×20	2		
4	139190014	六角法兰面螺栓M6×25	Hexagon bolt M6×25	1		
5	139300002	定位销Φ8×11	Pin, DowelΦ8×11	1		
6	139300003	O形圈Φ10	O-ringΦ10	2		
7	139300005	十字槽盘头螺钉M4×10	Cross bolt M4×10	3		
8	139300006	机油泵体定位销	Oil pump pin	1		
9	139300007	机油泵盖	Oil pump cover	1		
10	139300008	机油泵体	Body, oil pump	1		
11	139300009	内转子	Rotor, oil pump inner	1		
12	139300010	油泵轴	Oil pump axis	1		
13	139300011	外转子	Rotor, oil pump outer	1		
A	139000004	机油泵总成	Oil Pump assembly	1		

齿轮室及盖 Gear chamber and cover



序	件号	中文名称	英文名称	数量	单价	
NO.	Code name	Chinese	Description	Q'ty	¥	\$
1	139150004	六角法兰面螺栓M8×35	Hexagon bolt M8×35	5		
2	139320001	六角法兰面螺栓M8×40	Hexagon bolt M8×40	2		
3	139320002	六角法兰面螺栓M8×12	Hexagon bolt M8×12	2		
4	139320003	纸垫片	Paper washer	9		
5	139320004	齿轮室盖	Gear room cover	1		
6	139320005	定位销Φ10×20	Pin, dowel Φ10×20	2		
7	139320006	齿轮室盖纸垫	Gear room cover paper washer	1		
8	139320007	最终轴	Final Shaft	1		
9	139320008	最终齿轮	Final Gear	1		
10	139320009	副轴组	layshaft assy	1		
11	139320010	副轴组垫片12×20	Layshaft washer12×20	1		
12	139320011	最终轴卡簧	Clip spring	1		
13	139320012	最终轴油封	oil seals	1		
14	139320013	轴承6004	Gearing 6004	1		
15	139320014	轴承6201	Gearing 6201	2		
16	139320015	六角法兰面螺母(专用)	Hexagon nut	1		
17	139320016	刹车蹄块定位销	Brake shoe pin	1		
18	139320017	O形圈Φ8×1.5	O-ringΦ8×1.5	1		
19	139320018	输入轴	Input axis	1		
20	139320019	轴承6203	Gearing 6203	1		

车架 Frame



序 NO	件号 Code name	中文名称 Chinese	英文名称 Description	数量 Q'ty	¥	单价 \$
1	0201-50STT	车架	Frame	1		
2	02011358	车架固定架	Fix board	1		
3	02011357	减震连接件	Shock seat	1		
4	02011346	塑件固定支架	Body covering fork	1		
5	02011348	电池盒左固定架	Battery case left bracket	1		
6	02011349	电池盒右固定架	Battery case right bracket	1		
7	02011354	吊架摇臂左	Hanger Rock Arm Left	1		
8	02011355	吊架摇臂右	Hanger Rock Arm Right	1		
9	02030287	方向柱	Steering Column	1		
10	02030285	上联板	Up connection plate	1		
11	02030283	方向把卡座	Handbar Raiser	2		
12	12030052	钢碗	Steel Bowl	1		

油箱、减震 Fuel Tank, Shock



序 NO	件号 Code name	中文名称 Chinese	英文名称 Description	数量 Q'ty	¥	单价 \$
1	01990040	二次补气装置	Secondary Air injection Device	1		
2	02010351	二次补气阀固定片	Air Injection Fixture	1		
3	07010122	前减震器左	Front Shock left	1		
	07010123	前减震器右	Front Shock Right	1		
4	12050018	轴用卡簧15	Circlip 15	1		
5	02050045	搁脚左	Footrest left	1		
6	02050046	搁脚右	Footrest right	1		
7	05030052	油箱	Fuel Tank	1		
8	03030769	后泥板	Rear fender	1		
9	07010125	后减震	Rear Shock	1		
10	02011343	单撑	Side Stand	1		
11	07020062	弹簧	Spring	1		

覆盖件1 Body Covering



序	件号	中文名称	英文名称	数量	单价	
NO	Code name	Chinese	Description	Q'ty	¥	\$
1	03010502	左侧盖前端	Left Board part 1	1		
2	03030755	左侧盖装饰板	Left Board part 2	1		
3	03030751	左侧盖前连接条	Left Board part 3	1		
4	03010504	左侧盖后端	Left Board part 4	1		
5	03010515	电池盒装饰盖左	Left Board part 5	1		
6	03030767	左侧盖下连接条	Left Board part 6	1		
7	03010513	电池盒上连接条左	Left Board part 7	1		
8	03030764	电池盒罩左	Left Board part 8	1		
9						
10						
11						
12						
13						
14						
15						
16						
17						
18						
19						

坐垫、后视镜 Seat, Mirrors



序 NO	件号 Code name	中文名称 Chinese	英文名称 Description	数量 Q'ty	¥	单价 \$
1	06020146	油箱前胶垫	Gas Tank rubber ring	2		
2	06020144	尾灯橡胶	Tail light rubber	3		
3	06020141	大灯支架上下橡胶	Headlight bracket rubber	4		
4	06020143	仪表胶垫	Iron Clamp	3		
5	15030032	油箱前翻边衬套	Gas Tank bushing	2		
6	06990001	二级过滤器	Secondary Fuel Filter	1		
7	12010010	钢丝卡子6	Iron Clamp	2		
8	06020147	油箱盖外罩胶垫	Gas tank rubber washer	1		
9	06020145	油箱后胶垫	Gas tank rear rubber washer	2		
10	06020142	转向灯支架胶套	Rubber of indicator	2		
11	06020149	随车工具压条	Tool rubber ring	1		
12	15030033	坐垫锁盒翻边衬套	Seat lock rubber ring	1		
13	10060001	油箱开关	Pet Cock	1		
14	12010007	油管夹8.5	Fuel Pipe Clamp 8.5	8		
15	06030001	真空管4*7	Gas Pipe 4*7	30cm		
16	06030002	汽油管4.5/8.5	Fuel Pipe 4.5/8.5	105cm		
17	05010059	坐垫	Seat	1		

