


# 猎鹰八代美国DOT-150cc状态表

序号	编码	CRT CODE	名称	EN DESCRIPTION	计量单位	PICTURE
1	QX-FL200-001		前护条		个	
2	QX-FL200-002		前面板		付	
3	QX-FL200-003		前轮泥板前部		个	
4	QX-FL200-004		前轮泥板后部		个	
5	QX-FL200-005		仪表前罩		个	
6	QX-FL200-006		左护条		个	
7	QX-FL200-007		右护条		个	
8	QX-FL200-008		左装饰板		个	
9	QX-FL200-009		右装饰板		个	
10	QX-FL200-010		后中心盖板		个	
11	QX-FL200-011		导流罩		个	
12	QX-FL200-012		前左风板		个	

13	QX-FL200-013		前右风板		付	
14	QX-FL200-014		仪表壳		付	
15	QX-FL200-015		工具箱		个	
16	QX-FL200-016		脚踏板		个	
17	QX-FL200-017		车架挡泥板		付	
18	QX-FL200-018		杂物箱		个	
19	QX-FL200-019		工具箱盖 (普通军绿)		个	
20	QX-FL200-020		杂物箱前罩		个	
21	QX-FL200-021		后轮挡泥板		个	
22	QX-FL200-022		车架号码盖		个	
23	QX-FL200-023		头盔挂钩		个	
24	QX-FL200-024		电瓶盒盖		个	
25	QX-FL200-025		保养盖		个	


26	QX-FL200-026		杂物箱内盖		个	
27	QX-FL200-027		工具箱压脚		个	
28	QX-FL200-028		小杂物箱		个	
29	QX-FL200-029		尾灯总成		个	
30	QX-FL200-030		前左转向灯		个	
31	QX-FL200-031		前右转向灯		个	
32	QX-FL200-032		大灯总成		个	
33	QX-FL200-033	09050002	侧反光牌		付	
34	QX-FL200-034	09050001	后反光牌		只	
35	QX-FL200-035	09050003	后左右反光牌		付	
36	QX-FL200-036		车架		只	
37	QX-FL200-037		方向把手		只	
38	QX-FL200-038		前面板支架		只	

39	QX-FL200-039		吊架		只	
40	QX-FL200-040		双撑		只	
41	QX-FL200-041		后轮挡泥板支架		套	
42	QX-FL200-042		单撑		只	
43	QX-FL200-043		油箱托架		只	
44	QX-FL200-044		座垫锁板组件		只	
45	QX-FL200-045		下联板		只	
46	QX-FL200-046		后牌照支架		只	
47	QX-FL200-047		仪表		只	
48	QX-FL200-048		座垫		只	
49	QX-FL200-049		后货架		只	
50	QX-FL200-050		套锁		只	

51	QX-FL200-051		传感器		只	
52	QX-FL200-052		油箱		只	
53	QX-FL200-053		油箱盖		只	
54	QX-FL200-054		前减震		付	
55	QX-FL200-055		后减震		只	
56	QX-FL200-056		碟刹泵		只	
57	QX-FL200-057		碟刹盘		只	
58	QX-FL200-058		六大开关		套	
	QX-FL200-058-1		电启动开关		只	
	QX-FL200-058-2		喇叭开关		只	
	QX-FL200-058-3		熄火开关		只	
	QX-FL200-058-4		远近光开关		只	
	QX-FL200-058-5		转向灯开关		只	

	QX-FL200-058-6		警示开关		只	
59	QX-FL200-059		主电缆		根	
60	QX-FL200-060		前左右转向灯线卡		只	
61	QX-FL200-061		左右把套		付	
62	QX-FL200-062		油门固定座		只	
63	QX-FL200-063		转速器		只	
64	QX-FL200-064		前铝轮		只	
65	QX-FL200-065		后铝轮		只	
66	QX-FL200-066		前轮胎		只	
67	QX-FL200-067		后轮胎		只	
68	QX-FL200-068	190225	气门嘴		只	
69	QX-FL200-069		左刹把总成		只	

70	QX-FL200-070		手刹线		只	
71	QX-FL200-071	08020052	里程线		只	
72	QX-FL200-072		油门线		只	
73	QX-FL200-073	08020057	座垫锁线		根	
74	QX-FL200-074	10070001	喇叭		只	
75	QX-FL200-075		稳压器		只	
76	QX-FL200-076		继电器		只	
77	QX-FL200-077	01020016	点火器		只	
78	QX-FL200-078	01020011	闪光器		只	
79	QX-FL200-079	01020022	高压包		只	
80	QX-FL200-080	01030013-2	化油器		只	
81	QX-FL200-081	06990001	汽油过滤器		只	
82	QX-FL200-082	10060001	油开关		只	

83	QX-FL200-083	06030006	油管		根	
84	QX-FL200-084		气管		根	
85	QX-FL200-085		碳罐/倾倒阀		只	
86	QX-FL200-086		托付管		套	
87	QX-FL200-087		碳罐负压管		根	
88	QX-FL200-088		碳罐回气管		根	
89	QX-FL200-089		气管卡箍		只	
90	QX-FL200-090		汽油管卡簧		只	
91	QX-FL200-091		后轮连接板		只	
92	QX-FL200-092		空滤器		只	
93	QX-FL200-093		排气管		套	
94	QX-FL200-094	01990024	排气管垫片		只	

95	QX-FL200-095		单撑弹簧		只	
96	QX-FL200-096		双撑弹簧		只	
97	QX-FL200-097		双撑缓冲块		只	
98	QX-FL200-098		吊架橡皮		只	
99	QX-FL200-099		吊架堵头		只	
100	QX-FL200-100		上钢碗防尘套		只	
101	QX-FL200-101		钢碗		套	
102	QX-FL200-102		后视镜		付	
103	QX-FL200-103	10990001	电瓶		只	
104	QX-FL200-104		里程线夹		只	
105	QX-FL200-105		后轮泥板挡水皮		只	
106	QX-FL200-106		碟刹线夹		只	
107	QX-FL200-107		前轮衬套		只	Φ 12*22mm

108	QX-FL200-108		补气阀垫		只	
109	QX-FL200-109		补气阀		只	
110	QX-FL200-110		前轮轴		根	M12*250
111	QX-FL200-111	16990010	随车工具		套	
112	QX-FL200-112		后尾箱		套	