

# FRONTIER-QX-200坦克168cc零部件图册

序号	图片	编码	配件名称	英文名称	单位			备注
1		QX-FT200-001	后尾箱					
2		QX-FT200-002	左右边箱					
3		QX-FT200-003	尾箱支架					
4		QX-FT200-004	发动机		只			
5		QX-FT200-005	车架		只			
6		QX-FT200-006	下联板		只			
7		QX-FT200-007	方向把		只			
8		QX-FT200-008	双撑		只			
9		QX-FT200-009	单撑		只			
10		QX-FT200-010	方向把下接		只			
11		QX-FT200-011	动力吊架		只			
12		QX-FT200-012	前面板支架		只			

13		QX-FT200-013	左右转向灯支架		只			
14		QX-FT200-014	前泥板支架		只			
15		QX-FT200-015	前脚踏板支撑		只			
16		QX-FT200-016	前挡风板安装支架		只			
17		QX-FT200-017	后牌照支架链接		只			
18		QX-FT200-018	后牌照支架		只			
19		QX-FT200-019	座垫锁板		只			
20		QX-FT200-020	前围左装饰条		只			
21		QX-FT200-021	前围右装饰条		只			
22		QX-FT200-022	前围左装饰盖		只			
23		QX-FT200-023	前围右装饰盖		只			
24		QX-FT200-024	前挡泥板		只			

25		QX-FT200-025	左侧盖		只			
26		QX-FT200-026	右侧盖		只			
27		QX-FT200-027	注油箱口盖 (借用BWS 八代)		只			
28		QX-FT200-028	方向把座装 饰罩		只			
29		QX-FT200-029	面板装饰件		副			
30		QX-FT200-030	面板		只			
31		QX-FT200-031	大灯外罩装 饰件		只			
32		QX-FT200-032	大灯外罩		只			
33		QX-FT200-033	前围(左 部)		只			
34		QX-FT200-034	前围(右 部)		只			
35		QX-FT200-035	工具箱		只			
36		QX-FT200-036	工具箱内盖		只			

37		QX-FT200-037	车体护板前部		只			
38		QX-FT200-038	车体护板		只			
39		QX-FT200-039	脚踏板		只			
40		QX-FT200-040	电瓶盖		只			
41		QX-FT200-041	座桶前罩		只			
42		QX-FT200-042	座桶		只			
43		QX-FT200-043	尾灯外上罩		只			
44		QX-FT200-044	尾灯外下罩		只			
45		QX-FT200-045	后泥板		只			
46		QX-FT200-046	油箱护板		只			
47		QX-FT200-047	注油箱口装饰盖（借用BWS八代）		只			
48		QX-FT200-048	工具箱挂钩（借用BWS八代）		只			

49		QX-FT200-049	座桶内盖		只			
50		QX-FT200-050	脚踏板螺丝罩（借用BWS三代）		只			
51		QX-FT200-051	挡风玻璃（改装）		只			
52		QX-FT200-052	把手左护罩（改装）		只			
53		QX-FT200-053	把手右护罩（改装）		只			
54		QX-FT200-054	前减震护罩（改装）		副			
55		QX-FT200-055	发动机装饰罩（新款）		只			
56		QX-FT200-056	前大灯		只			
57		QX-FT200-057	前左转向灯		只			
58		QX-FT200-058	前右转向灯		只			
59		QX-FT200-059	后左转向灯		只			
60		QX-FT200-060	后右转向灯		只			

61		QX-FT200-061	牌照灯		只			
62		QX-FT200-062	尾灯		只			
63		QX-FT200-063	前侧反光牌		副			
64		QX-FT200-064	后反光牌		只			
65		QX-FT200-065	后左右反光牌		副			
66		QX-FT200-066	前面板加背包支架		只			
67		QX-FT200-067	方向把压块		套			
68		QX-FT200-068	脚蹬		副			
69		QX-FT200-069	后货架		只			
70		QX-FT200-070	套锁		套			
71		QX-FT200-071	钢碗		套			
72		QX-FT200-072	仪表		只			


73		QX-FT200-073	座垫		只			
74		QX-FT200-074	油箱		只			
75		QX-FT200-075	油箱盖		只			
76		QX-FT200-076	前减震		副			
77		QX-FT200-077	后减震		副			
78		QX-FT200-078	前碟刹泵		只			
79		QX-FT200-079	碟刹盘		只			
80		QX-FT200-080	里程感应盘		只			
81		QX-FT200-081	后碟刹		套			
82		QX-FT200-082	后碟刹盘		只			
83		QX-FT200-083	右开关		只			
84		QX-FT200-084	左开关		只			

85		QX-FT200-085	主电缆		根			
86		QX-FT200-086	前铝轮		只			
87		QX-FT200-087	后铝轮		只			
88		QX-FT200-088	前后轮胎 130/70-12		条			
89		QX-FT200-089	气嘴（含气帽）		套			
90		QX-FT200-090	油门线		根			
91		QX-FT200-091	座垫锁线		根			
92		QX-FT200-092	喇叭		只			
93		QX-FT200-093	稳压器		只			
94		QX-FT200-094	继电器		只			
95		QX-FT200-095	点火器		只			
96		QX-FT200-096	闪光器		只			



97		QX-FT200-097	高压包		只			
98		QX-FT200-098	化油器		只			
99		QX-FT200-099	汽油过滤器		只			
100		QX-FT200-100	油开关		只			
101		QX-FT200-101	空滤器					
102		QX-FT200-102	铝连接板		套			
103		QX-FT200-103	排气管		只			
104		QX-FT200-104	排气管垫片		只			
105		QX-FT200-105	单撑弹簧		只			
106		QX-FT200-106	双撑弹簧		只			
107		QX-FT200-107	左右把套		副			
108		QX-FT200-108	双撑缓冲块		只			

109		QX-FT200-109	吊架橡皮		只			
110		QX-FT200-110	上钢碗防尘套		只			
111		QX-FT200-111	吊架堵头		只			
112		QX-FT200-112	后视镜		副			
113		QX-FT200-113	电瓶		只			
114		QX-FT200-114	碟刹线夹		副			
115		QX-FT200-115	前侧反射器支架		副			
116		QX-FT200-116	方向把支架		只			
117		QX-FT200-117	里程线卡		只			
118		QX-FT200-118	线卡		只			
119		QX-FT200-119	磁电机线卡		只			
120		QX-FT200-120	后轮泥板		只			

121		QX-FT200-121	左右边箱支架		套			
-----	-----------------------------------------------------------------------------------	--------------	--------	--	---	--	--	--

















